bouncepad®

Core Counter


Assembly Instructions


Tools Required:


Socket Driver

Sheet Code: BP-IM-086_REV0 Release Date: 14/08/2024

Copyright 2024 Spotspot Ltd. (T/A Bouncepad) all rights reserved. Confidential, no part of this publication may be reproduced or transmitted in any form without the written permission of the copyright holder.












In the Box




Fixings List











Locate & secure the Desk Mounting Arm to the Freestanding Base.


Locate & attach the Shell 2 to the Desk in the correct orientation.


Remove the Mounting Plate adhesive 3 backing. Attach level & centrally to the Tablet back as shown.

Attach the Flat Cable to the Tablet with the U-Bend Head.









Secure the Flat Cable to the Mounting Plate with the Cable Clamp as shown.

5

6

Remove the Fixing Covers. Feed the Flat Cable into the assembly & locate the Tablet in the chosen orientation.

Covers as shown.

Connect tablet to power & installation is now complete.

Secure the Tablet to the Shell & attach the Fixing