## bouncepad

## **Core Flex**

## Assembly Instructions

- Tools Required:
- Pencil
- Electric Drill
- 7mm Spanner \*or adjustable spanner
- 5.0mm Drillbit \*if fixing from below
- 2.5mm Drillbit \*if fixing from above
- 16mm \*if routing the tablet cable through your Holesaw mounting surface
- Holesaw
- Sheet Code: BP-IM-082\_REV0 Release Date: 13/08/2024

Copyright 2024 Spotspot Ltd. (T/A Bouncepad) all rights reserved. Confidential, no part of this publication may be reproduced or transmitted in any form without the written permission of the copyright holder.

M4 Split washer

M4 Wing Nut

A5


Go to step 1.


Secure the arm to the

surface. Locking Nuts

offer higher security.

A4





(⊗

Using the Mount Plate,

mark the drill hole

locations as shown.

Front

**B1** 

Drill each hole - using the specified drill sizes.

 $\bigcirc$ 

Ø16.0mm Holesaw

**B2** 

